



BYRON FIRE PROTECTION DISTRICT
 232 WEST 2ND ST
 BYRON, IL 61010
 Quote For:

Foster Coach Sales *R
 Andrew Foster
 >>>Previous 4861, 2001 this unit is NOT
 a match<<<

Exp. Date: 11/23/2005
 Quote No: 10086-0012

AMBULANCE: PD-168-F PD-168, 168" x 96", Type I
 DEALER: Dealer Parts

10/29/2009

Job/Order No: 6919

Page 1

PART NO	S	DESCRIPTION	QTY
		== PD-168, 168" x 96", Type I - 5.007 08/22/05 ==	1
01-00-0000	S	VIN # 1FDXF46P96ED06744	1
	S	6-19-06 reconciled for production with vin number/kre	
		7-5-06 Re-reconciled for change in airhorns which would change the option pricing/kre	
		7-17-06 Re-Reconciled for change in Fin Amount/kre	
		7-20-06 Re-reconciled for changes from the production floor/kre	
01-01-0400	S OPT	Ford FIN/GPC Discount/Concession	1
	S	INSTRUCTION:	
		1) FIN CODE:QN 448	
		2) APPROVAL DATE: approved by MCBG on 7-14-06 with copy on file	
01-02-03A	X OPT	DEPOSIT, Prepay Byron ck#29037, 2-13-06	1
01-02-0400	S OPT	Prepayment Discount	1
	S	PrePay Discount applied @ 5% @ 150 days on 3/7/06	
01-02-05A	X OPT	Prepay discount error in posting	1
	S	7-18-06 needed to add to reconcile as prepay was off a penny/kre	
10-06-2000	S	2006 Base Conversion, PD-168-F Type I	1
	S	Order received 12-21-05 and was NOT price protected, so this is a 2006 Conversion.	
10-08-0400		Completed Vehicle Dim/Curb Weight/Payload Allowance 450 4x2	1
11-06-0900		72" Headroom (PD-168-F)	1
12-00-1000		EXTERIOR "A" COMPARTMENTS - CURB SIDE (72" HR) PD-168-F	1
12-02-0600		Type I, Class I, Two-Door Cab/Chassis Tech Requirements	1
		*** CHASSIS MAKE & MODEL ***	1
12-08-0800	S	Ford F-450 Cab/Chassis, 4 x 2, 2006	1
	S	INSTRUCTION:	
		189" wheelbase	
		15,000 LB GVW	
12-13-0400		Rear Air Ride System With Lowering Kit, Link System	1
	S	- Low PSI light in front switch panel.	
		- Dump automatically activated by the streetside rear entry door.	
		- Dump cancel switch beside STREETSIDE rear entry door	
14-02-0000		*** CHASSIS COMPONENTS ***	1
14-12-1600		Front & Rear Tires, 225/70R19.5E	1
		INSTRUCTIONS:	
		Steel belted radials with all season tread.	

PART NO	S	DESCRIPTION	QTY
14-14-0400		Spare Tire, Radial All-Season-Match Vehicle Tires-Ship Loose LOCATION: SHIPPED LOOSE	1
14-16-1200		Rear Axle, 11,000# Rating at Ground With Springs	1
14-18-0200		Front OEM Sway Bar & Rear IPD Sway Bar (Std) INSTRUCTION: OEM front sway bar. Add IPD sway bar to rear axle	1
14-22-0200		Shock Absorbers, OEM, Front & Rear	1
14-24-0400		Ford Electric Throttle, OEM Preset RPM	1
16-02-0000		*** CHASSIS INTERIOR COMPONENTS ***	1
16-02-0800		Driver's Compartment Appointments, Ford F	1
16-02-2000		OEM AM-FM Radio & CD - Standard location	1
	S	7-20-06 Andrew wants the new fiberglass console and the OEM radio will NOT fit in it per Tony. Do not move the OEM Radio. Tony was advised by phone and fax	
16-14-0600		Cab Sign, "No Smoking, Oxygen Equipped" & "Fasten Seatbelts" INSTRUCTION; (1) on passenger side of dash.	1
16-16-0400	OPT	Cab Flooring, Rubber, ILO Ford OEM Carpeted Floor INSTRUCTION: Install rubber flooring in chassis cab.	1
16-21-0000		Battery Switch - TST Commander 350 With 5 Minute Timer	1
16-24-0200		Chassis OEM Engine Block Heater, Wire To Shoreline *** CHASSIS EXTERIOR ACCESSORIES ***	1
18-04-0600	OPT	Tire Chain System, Rudd With Switch In Cab	1
	S	INSTRUCTIONS: Air activated chains. Mount compressor in compartment D-4. Keep cage as small as possible. Air reservoir mounted under body. (1) cover-protected switch in front switch panel.	
	S	>>The air horns and tire chains will share the large compressor. Keep the cage to this compressor as small as possible and as rearward as possible in the compartment<<	
18-06-0400		Wheel Simulators, Dicor - Stainless Steel	1
18-12-0200		Tire Fill Extensions (4)Dicor, For Rear Inside/Outside Tires	1
		*** 12 VOLT ELECTRICAL SYSTEMS AND COMPONENTS ***	
20-02-0100		LABEL ALL BREAKERS ON SIDE OF DRIVERS SEATBASE	1
20-02-0200		Vehicle Wiring, Type I, Class I	1
20-04-0400		Alternators, (2) Motorcraft, OEM with Ambulance Prep Pkg INSTRUCTION: Motorcraft Ford OEM installed.	1
20-06-0200		Wiring Module, Angled Electrical Cabinet	1
21-02-0000		Portable Equipment Charging Circuits INSTRUCTION: (1) 20 amp circuit breaker. Run power wires from drivers seatbase to: (1) Circuit (power & ground) to front console - labeled on both ends: "Portable Equipment Charging Circuit". (1) Circuit (power & ground) to behind rear switch panel - labeled on both ends: "Portable Equipment Charging Circuit". (Requires optional inverter or battery charger for full function.)	1
22-04-0400		Front Console, Center Cab Mount	1

PART NO	S	DESCRIPTION	QTY
	S	INSTRUCTION: Install Rocker switch panel on front console.	
		7-20-06 per andrew use the new fiberglass console and DO NOT move the OEM radio.	
24-02-1000	S	(2) Batteries, 1500 CCA INSTRUCTION: Dual OEM relocated to the battery drawer	1
24-04-0400	OPT S	(1) Battery, Additional, 750 CCA, 2250 CCA Total INSTRUCTION: Install additional battery in P-2 battery drawer. Drawer will need to be deeper (21.75"D) to accommodate this third battery	1
24-12-0400	S	Outlets, (2) - 12 Volt, Cigarette Style, ALS & 1st AA INSTRUCTION: (1) in ALS cabinet (1) on 1st action area wall, up high in line with other gauges SEE PRINTS	1
		* * * 115 VOLT ELECTRICAL SYSTEMS AND COMPONENTS * * *	
26-04-0800	OPT S	Inverter, Vanner, Model #20-1050CUL LOCATION: Inverter installed under the passenger seat. (1) On/off switch in the rear switch panel	1
26-10-1600	OPT	Shoreline, 20 Amp Kussmaul Super Auto-Eject With Dynamic Dis. LOCATION: On driver's side. INSTRUCTION: (1) 115 volt 20 amp. (60Hz) Kussmaul Super Auto-eject with dynamic disconnect. Water-tight cover. SHIP LOOSE PIGTAIL	1
26-16-2800		Outlets, (3) Interior, 115V (ALS Cabinet, 1st AA, & 2nd AA) LOCATION: (1) in ALS cabinet (1) in 1st action area (1) in 2nd action area SEE PRINTS	1
26-22-0400		Spotlight, (1) Optronics "BlueEye 4000", Hand-Held, Hard Wire LOCATION: Wired to drivers seatbase. SHIP LOOSE HANGING HARDWARE.	1
		* * * AUDIO WARNING DEVICES * * *	
28-02-3200	OPT	Siren, E-Q2B, Electrical INSTRUCTION: Break switch located in front console. Speaker located at front bumper.	1
28-06-2400	S	Speakers, Bumper Mounted, #SAD & SAP 4312-05FSD-1 >>>Foster Coach will warrant the siren speakers to the customer NOT Medtec per Steve Foster 12-5-05<<<	1
28-08-1200	S OPT	Air Horn Kit, (2) Buel Trumpets, Thru the Bumper INSTRUCTION: (2) Buell Trumpet 10" & 12" (1) T5240 Compressor mount in D2 compartment. (1) VEL 1488 ci reservoir tank Solenoid #32076	1
	S	7-5-06 changed to Buell so that they can go thru the bumper per Dale Jacobs and Andrew Foster.	
28-08-13A	U OPT	Compressor, Credit the small compressor	1

PART NO	S	DESCRIPTION	QTY
	S	Air horns and tire Chains will run off of the large compressor per Andrew on 12-22-05 email	
28-10-0200	S	Horn Ring, Switch, Siren/Horn/Air Horn INSTRUCTION: (1) switch in front switch panel	1
28-14-0200		Backup Alarm, Preco #230 With Auto Reset Switch INSTRUCTION: (1) Automatic reset cancel switch, mounted in front switch panel.	1
		* * * VISUAL WARNING DEVICES * * *	1
	S	>>>All lights to Double Flash<<< Install Whelen AFL530 ILOS Vanner Flasher	
30-03-1200	S	Clearance Lights, LED, (14) With Chrome Bezel INSTRUCTION: (4) lights - two on each side, of upper body corner extrusions. (5) on the rear and (5) on the front, upper body extrusions.	1
30-04-0200		No Headlight Flasher Required At This Time	1
30-09-8200	OPT	Lights, Whelen 600 LED, Stop & Tail, 900 LED, Turn W/ Arrow LOCATION: With Flanges. Backup lights - halogen. Tail and backup lights on module rear, in kickplate. Turn lights on rear of module box. SEE PRINT	1
30-12-0000		CHASSIS GRILLE LIGHTS	1
30-14-2800	S	Grille Lights, (2) Whelen 700 Super LED, Red/Blue Lenses INSTRUCTION: With Cast low profile bezels. Red/Blue split super LED and Lense Blue is outboard on Curbside Red is Outboard on Streetside	1
30-18-0000		INTERSECTOR LIGHTS	1
30-22-0600	S	Intersector Lights,(2)Whelen 700 Super LED,Red/Blue Split,Wi INSTRUCTION: Red/Blue Split Super LED & Lense Blue Forward on Curbside Red Forward on Streetside With cast bezels	1
30-30-0000		LIGHTBARS - FRONT OF VEHICLE	1
30-30-1800	OPT	Front Lightbar, Whelen 86" LED Edgebar - #4500-KKKFL, INSTRUCTION: 2 - Corner angled linear (1)red (1)blue super LED, 6 - 400 series linear (3)red (3)blue super LED flashers, 1 - 400 series center linear clear LED flasher Super LED & Lens colors from driver side: R/B/R/B/C/R/B/R/B Internal Auxiliary Flasher (1) switch in front switch panel.	1
30-30-19A	U OPT	Flasher, additional Whelen AFL530 Additional flasher is required so that the super linear lightbar will double flash with the rest of the unit per Guy Staples and approved by AF.	1
32-02-0000		FRONT OF BODY LIGHTS	1
32-02-2800	OPT	DELETE (3) Upper Front Body Lights	1
32-10-2000	OPT	Additional Front Body Side Turn Lights, Whelen 700 LED INSTRUCTION: Install on upper front corners of module box.	1

PART NO	S	DESCRIPTION	QTY
		With Flanges. Amber lenses with arrows.	
32-12-0000		SIDE OF BODY WARNING LIGHTS	1
32-16-1200	S	Side Body Lights, (4) Whelen 900 Super LED, Red & Blue W/Flng	1
	S	LOCATION: Red and Blue Super LED & Lense With Flanges (2) Streetside (1)BLUE is rearward (1) RED is forward (2) Curbside (1)BLUE is forward (1) RED is rearward	
32-18-0600	OPT	Side Turn Lights, Whelen 700 LED	1
	S	INSTRUCTION: With Flanges. Red LED & Lenses. (1) Each side of body at rear. Steady burn with DOT lights. Flash with turn signals.	
32-20-2200	S OPT	Rear Wheel Well Lgts, (2) Whelen 700, Super Red/Blue LED/Len	1
	S	LOCATION: With Flanges Mounted over rear wheelwells. Red and Blue super LED & Lense	
	S	RED ON DRIVER BLUE ON PASSENGER	
32-22-0000		SIDE SCENE LIGHTS	1
32-22-0700		Scene Lights, (4) Whelen 900 Opti-Scene 8-32 degree (Flange)	1
		INSTRUCTION: With Flanges. (2) Streetside (2) Curbside (1) switch in front switch panel, for each side.	
32-24-0200		Scne Lgts Activatd, Rearmost W/Reverse & Curbside W/Side Door	1
		INSTRUCTION: Curbside scene lights to activate with side entry door. Rearmost scene lights to activate in reverse.	
34-02-0000		REAR BODY LIGHTS	1
34-10-1400	OPT	Rear Lightbar, Whelen, 86" Edgebar - LED #4500-KKKR LED	1
	S	INSTRUCTION: (1) switch in front switch panel for lightbar. Super LED & Lense colors: R/B/R/LOAD/A/LOAD/R/B/R Load lights included in rear lightbar. Activate with rear doors and reverse. (1) On/off switch in front switch panel for load lights.	
34-10-2200	OPT	Arrowstik, Whelen LED Traffic Advisor - Model TAL85	1
		INSTRUCTION: Surface mount traffic advisor on rear of module box - above rear entry doors. Mount control head in front console.	
34-11-03A	X OPT	Whelen 2022LC Flash4 Strobe Beacon w/cast bezel	1
	S	22 WATT Pipe/Flat Low dome with aluminum cast bezel 7-19-06 Per Andrew's email, put a switch in the front switch panel to operate this beacon. Brad was advised by phone and fax.	
	S	Locate: on rear center of module roof	

PART NO	S	DESCRIPTION	QTY
34-16-0800	S OPT	Rr Bdy Lgts,(2) Mid-Hght, Whelen 900 5mm LED, Red W/Flange	1
	S	INSTRUCTION: With Flanges. Use "Old Style" LED unless Whelen has corrected the wire to brake issue with the super LED's.	
		To shine through rear windows when doors are open.	
34-38-0200		Warning Light Flash Requirements, "E-Spec" Flash Pattern	1
36-09-3200	S OPT	Wire [2] Lights to Brakes, Brakes Override Flashers	1
	S	INSTRUCTION: Wire mid height lights to brake override.	
		* * * BODY DESIGN AND CONSTRUCTION COMPONENTS * * *	1
40-07-0200		Compartment & Entry Doors With Recessed Door Liner	1
40-08-1200	S	Exterior Compt. Depth, 18.75" (Back Board Compt. 23.5")	1
	S	Battery drawer is 21.75"D	
40-10-0200		Insulation,Dolphin Protective Coating,Kraft Fiberglass Batts	1
		INSTRUCTION: 2" Kraft-faced fiberglass batts on walls and ceiling.	
40-12-0200	S	Heat Shields, 18 ga. Galvanized Steel, Vapor Barrier	1
	S	LOCATION: Below Subfloor and to bottom of floor tubes	
40-12-1200		Fender Insulator, Flash Patch Liner, Over Rear Wheelwells	1
40-14-1800		Cab Connection, 16 Gauge Steel, Pass-Thru, Ford F-450	1
		INSTRUCTION: EPDM rubber bellows held in place with rolled steel flexible cores	
40-18-0400		Body Mounting, Isomount Technique, 3/4" x 6" Alum, 10-Bolt	1
		INSTRUCTION: 3/4" x 6" alum plates, ten (10) bolts. Bolts and paired rubber isolators with steel cap and collared mounting nut for each chassis manufacturer mounting point.	
40-20-3100		* * EXTERIOR COMPARTMENTS - STREET SIDE (72" HR) PD-168-F	1
40-24-1100	S	D1, Exterior Compartment, 36" W x 84" H	1
	S	>>Modification to standard compartment width<< Lined with smooth aluminum, rubbermatted.	
40-32-0200	S	D1, Doors, Double Solid, Vertically Hinged	1
	S	>>Modification to standard compartment width<<	
42-02-2300	S	D2, Exterior Compartment, DELETED	1
42-10-0800		D3, Exterior Compartment, Not Required At This Time	1
42-16-3900	S	D4, Exterior Compartment, 35" W x 38" H (Outside)	1
	S	INSTRUCTION: This compartment to have outside access ONLY. >>Modification to standard compartment Height<<	
42-18-0200	S	D4, Doors, Double Solid, Vertically Hinged	1
	S	>>Modification to standard compartment Height<<	
44-00-0000		* * EXTERIOR COMPARTMENTS - CURB SIDE * *	1
		LOCATION: Exterior compartments, passenger side	
44-04-2000	S	P1, Exterior Compartment, 23" W x 53" H, ALS	1
44-06-1000		P1, Door, Solid, Vertically Hinged	1
44-08-1000	S	P2, Exterior Compartment, 23" W x 14" H, Battery Drawer	1
	S	INSTRUCTION: Slide-out tray with battery mounts. This compartment needs to be 21.75" Deep to accommodate the	

PART NO	S	DESCRIPTION	QTY
		third battery.	
44-10-0200		P2, Handle, Tri-Mark With Lock	1
44-12-1800		Side Entry Door, 32" W x 74" H	1
	S	INSTRUCTION: With Dual Firegrade ADP stepwell.	
44-14-3400	OPT	Door Panel, Side Entry, Three-Piece, Formica & Stainless Steel	1
		INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior.	
44-15-0000		Stepwell Light, Whelen 4" Round LED with Chrome Flange	1
44-16-1000	OPT	(2) Gloveboxes, Above Side Entry Door	1
		INSTRUCTION: Recessed into headpad. Flip up plexiglas doors.	
44-16-1200	S	Assist Handle, Brey Krause, Side Entry, 1.5" x 45 Degree	1
		LOCATION: Interior of side entry door.	
		>>Proper operation of MVP armrest and ALS Drug Draw may require a Brey Krause 1.5" x Straight assist handle on the side entry door<<	
44-32-2300	S	P5, Exterior Compartment, 34" W x 30" H	1
	S	>>Modification to standard compartment width<<	
44-34-0200		P5, Door, Solid, Vertically Hinged	1
48-12-0000		* * REAR BODY PATIENT ENTRY DOORS * *	1
48-12-1000		Rear Entry Doors, 50" W x 63" H, Dual Tri-Mark Handles	1
		INSTRUCTION: Driver side - non-locking. Passenger side - locking.	
48-14-3400	OPT	Door Panel, Rear Entry Doors, Three-Piece, Formica & Stainless	1
		INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior.	
48-16-0800		Assist Handle, Brey Krause, Rear Entry, 1.5" x 45 Degree	1
		LOCATION: Interior of rear entry door.	
48-22-0600	OPT	(2) Gloveboxes Above Rear Entry Doors	1
		INSTRUCTION: Recessed into headpad. One on left side, one on right side. Flip up plexiglas doors.	
48-24-1000	OPT	(1) Clock, 6.5" Trintec, Above Rear Entry Doors - Hinged	1
	S	LOCATION: Above rear entry doors, on head pad. Top hinge and bottom ball catch for easy access to change battery.	
49-00-0000		* * WINDOWS * *	1
49-02-0400	OPT	Sliding Window, Side Entry Door, Bronze Glass	1
		INSTRUCTION: (1) 18" x 19"	
49-04-0800	OPT	Fixed Windows, Rear Entry Doors, Bronze Glass	1
		INSRUCTION: (2) 18" x 19"	

PART NO	S	DESCRIPTION	QTY
		*** EXTERIOR COMPARTMENT COMPONENTS ***	
50-00-0500		Exterior Compartments, ADP With "Sweep Out" Design	1
	S	D1 is lined with smooth aluminum, rubbermatted	1
50-02-0200		Exterior Compartments, Gas Charged Door Hold Opens	1
		LOCATION: On exterior compartment doors. Spring cam hold open on side entry door. Open greater than 90 degrees were applicable.	
50-02-0600		Exterior Compartment Doors, Tri-Mark Handles	1
		INSTRUCTION: Tri-Mark paddle latches keyed alike.	
50-03-0000		Exterior O2 Vent - On O2 Compartment Door	1
		INSTRUCTION: (1) #1031 O/2 vent - exterior compt. door - of O/2 compt. (1) small black plastic vent - interior of compt. door on door liner.	
50-04-0400		Exterior Compartments, Black Dri-Deck On Floor & Shelves	1
50-06-0000		Rear Door Grabbers, Cast Products "Grabber"	1
		INSTRUCTION: Bottom of rear entry doors.	
50-06-0400		Door Seals, Automotive Closed Cell Gasket	1
		LOCATION: Exterior compartments & entry doors	
50-06-1200	OPT	Power Door Lock System, All Doors - Compartment and Entry	1
		INSTRUCTION: Except drawers. Install power door locks with switch in front switch panel.	
50-06-1600	OPT	Power Door Lock Switch, (1) Additional, Exterior Hidden	1
	S	LOCATION: License Plate Bezel	
50-06-3200	OPT	Power Door Lock Switch, (1) Additional In Patient Compartment	1
	S	LOCATION: Locate on the curside wall by the side entry door	
50-06-4200	OPT	Wire Power Door Locks To OEM Chassis Door Locks	1
50-07-0300		Stainless Steel Door Sills - All Exterior Compartments	1
		INSTRUCTION: On upper ledge.	
50-08-0200		Exterior Compartment Lights, Litco	1
		INSTRUCTION: Activated by compartment doors.	
		*** EXTERIOR COMPARTMENT EQUIPMENT ***	
50-10-0200		D1, (1) O2 Tank Mount, Stainless Steel Rings - "M" Cylinder	1
		INSTRUCTION: Adjustable	1
50-12-0400	OPT	D1, Vertical Fixed Divider for Backboard	1
	S	INSTRUCTION: Install (1) aluminum, Full Height, rubbermat covered, fixed divider 11" from the rearward wall of compartment. Leave enough room to service the tank but put the divider as close as possible to accomplish that.	
50-12-1700	OPT	D1, (1) Adjustable Shelf	1

PART NO	S	DESCRIPTION	QTY
	S	Locate rearward of full height divider above the O2 viewing window	
50-14-0100	OPT	D2, Delete Standard Adjustable Shelf	1
50-16-1700	S	D4, (1) Adjustable Shelf Full height in compartment	1
		*** EXTERIOR BODY COMPONENTS ***	1
50-24-0600		Grab Rail, 16" - To The Left Of Side Entry Door	1
50-27-0400		Weld & Finish Side Seams	1
50-32-0800	S	Bumper, Rear With 8" Diamond Back Flip Step Full width ADP kickplate below the rear entry doors	1
50-34-0600		Bumper Pods, Cast Aluminum With Logo	1
50-38-0600		Body Protection, Rear Mudflaps & "C" Channel Rubrails "Pierce" style "C" channel rubrails.	1
50-40-0400		Fuel Entry, Driver Side, Above & Behind Wheelwell	1
50-42-0600	OPT	Running Boards, Fire Grade ADP w/ Diamond Back Grip & Mudflap	1
50-42-1600	OPT	Stoneguards, ADP, 30" Front - 12.5" Rear	1
50-44-0200		Fenderettes, Rear, Stainless Steel	1
50-46-0800		License Plate Holder #LP0002-1, Recessed On Driver's Side LOCATION: With (2) top lights. Rear drivers side, below turn signal.	1
50-50-0200		Ziebart Undercoating, Chassis & Body (Standard) *** INTERIOR PATIENT COMPARTMENT COMPONENTS ***	1
52-05-0200		Cabinet Glass - Smoked Acrylic 1/4" Plexiglass	1
52-06-0200		Stainless Steel Round Southco Locking Latches, Standard INSTRUCTION: All interior cabinet doors to have, Stainless steel locking round Southco latches.	1
52-11-0600		Cabinetry, Patient Compt, Wood With Formica (Radius) INSTRUCTION: -- 5" RADIUS CORNERS -- Corner on ALS cabinet. Upper corners of streetside cabinets. Corner on squad overhead cabinet.	1
52-28-0600	OPT S	Dome Lights, (6) + (2) 39" Fluorescents INSTRUCTION: (2) - 3 position switches in the rear switch panel (1) for each bank of dome lights. A three-minute time delay system activated by the patient entry doors. (2) Thinlite brand 39" fluorescent lights to be installed. (1) On/off switch in the rear switch panel, for both fluorescent lights.	1
52-32-0200		Ceiling In Patient Compt, Pads Over Center Access INSTRUCTION: The ceiling to have access to antennae bases/leads. Covered by center ceiling pads.	1
52-34-0400	OPT S	Conduit, 2" Fixed INSTRUCTION: (1) 2" fixed conduit to run, from behind the driver cab seat, underneath vehicle, to the 1st action area, behind right side access panel.	1

PART NO	S	DESCRIPTION	QTY
52-36-0600	OPT	<i>Thinlite Light, 18" - Surface Mount In 1st Action Area</i>	1
52-54-2000		Flooring, With 5" Roll-up	1
52-60-0400		Rear Threshold, 6" Wide Stainless Steel With 2" Skid tape	1
		INSTRUCTION: 6" wide stainless steel threshold with 2" wide skid tape covering the threshold screw heads.	
		INTERIOR COLOR SECTION	
53-02-1800	OPT	<i>Formica Color, White (#949)</i>	1
53-03-0200	OPT	<i>Matte Formica Finish</i>	1
53-06-1600	OPT	<i>Flooring Color, Midnight #443, LonPlate II (Black)</i>	1
53-33-1200	OPT	<i>Upholstery Color, Desert Rose #MV106 (Brick Red)</i>	1
		*** STREETSIDE CABINETS - PATIENT COMPARTMENT ***	
	S	>>>All drawers are to be retrofitted with the 250 pound drawer slides with extra lips, except any airway drawers.<<<	
54-02-0800	S	<i>Sect 1 - 1st Action Area With 3/4" Lip</i> >>The 1st AA will be smaller than standard as there is NO Notch in D1	1
54-08-0400	OPT	<i>Sect 1, Radio Cutout With Black Kydex Cover 1st AA</i>	1
	S	INSTRUCTION: (1) cutout for installation of a radio installed in the 1st action area with a 1/4" black Kydex cover.	
54-12-1000	OPT	<i>Sect 1, No Clock In Rear Action Area At This Time</i>	1
54-14-0400	OPT	<i>Sect 1, Speakers For Radio, In Rear Ceiling</i> INSTRUCTION: (2) rear speakers in ceiling. Volume control (fader) in 1st action area.	1
54-16-2600	S	<i>Sect 1, 1st AA Overhead Cabinet</i> INSTRUCTION: NO Fixed center divider (1) adjustable shelf	1
	S	Cabinet will be cut back. There is to be NO notch into D1. Make cabinet as large as possible without this notch	
54-18-0600	OPT	<i>Sect 1, Restocking Plexiglass Doors On Overhead Cabinet</i> LOCATION: On the cabinet above 1st action area.	1
54-20-0200		Sect 1, Handles, Full Length Aluminum LOCATION: On the cabinet above 1st action area.	1
54-28-4400	OPT	<i>Sect 1, Writing Tray, 6" H x 14" W</i>	1
	S	INSTRUCTION: With round SS Locking Southco Latch. Install gas charged hold opens underneath. Gas strut to hold	

PART NO	S	DESCRIPTION	QTY
		open and closed.	
		See Photo with order.	
54-36-3200	S	Sect 1/2, No Cabinet Below 1st AA At This Time	1
54-48-0800	OPT	Sect 1, Suction Cabinet, Pull-Out INSTRUCTION: Plexiglas door with suction bracket mounted to it. Notch door for suction hose.	1
54-49-1200	OPT	Notebook Storage Under 1st AA INSTRUCTION: An open notebook slot shall be provided under the tray. Slot shall be 14" Deep with a 1/4" lip on the bottom of the opening.	1
56-02-0400	S	Sect 2, Sharps & Waste Compartment - DELETED	1
	S	Deleted sharps and waste Rearward of the CPR seat	
56-04-0400	S	Sect 2, Double Cabinet Above CPR Seat (2) equally sized cabinets to accommodate the 43" CPR Seat	1
56-06-0200	S	Sect 2, Flip-up Plexiglass Doors On Cabinets Above CPR	1
56-08-0200		Sect 2, Handles, Chrome "C" With Mini-strut Holdopens LOCATION: On cabinet above CPR seat.	1
56-26-0400	S	Sect 2, 2nd Action Area With 3/4" Lip Will be much smaller due to the 43" CPR Seat, just like in unit 6248	1
56-27-04A	U OPT	Sec 2, CPR SEAT TO BE 43" WIDE	1
	S	Cpr Seat to be widen to match unit 6248 See Print and photo attached of 6248	
58-02-0800	S	Sect 3, Overhead Cabinet, Rearward INSTRUCTION: NO Fixed center divider (1) adjustable shelf	1
58-04-0600	OPT	Sect 3, Restocking Plexiglass Doors, Rear Overhead Cabinet	1
58-06-0200		Sect 3, Handles, Full Length Aluminum LOCATION: On the upper rear streetside overhead cabinet.	1
58-08-1000	S	Sect 3, Cabinet, Inside Access	1
	S	INSTRUCTION: Lower rear streetside main cabinet inside access only due to shortened D4 with [2] adjustable shelves.	
58-30-0200		Sect 3, Plexiglas Doors, Double Sliding LOCATION: Lower rear streetside main cabinet.	1
58-32-0200		Sect 3, Handles, Full Length Aluminum	1
58-32-04A	X OPT	Sect. 3, 12 Volt Pre-wire in Cabinet	1
	S	Locate at floor level, forward	
58-46-0600		Sect 3, Exhaust Fan, 240 cfm Air Flow INSTRUCTIONS: Install (1) standard exhaust fan - streetside rear. Install a fan speed switch in rear switch panel	1

PART NO	S	DESCRIPTION	QTY
*** BULKHEAD COMPONENTS ***			
60-02-0200		B1, L/S, Oxygen Compt, Interior Access With 0/2 View Window INSTRUCTIONS: Hinged plexiglass door for O/2 view into D-1 compartment.	1 1
60-02-0800		B1, L/S, Electrical Cabinet, Angled INSTRUCTION: An angled cabinet shall house the electrical components.	1
60-04-0200	S	B1, Electrical Cabinet Door With Round Locking Southco Latch INSTRUCTION: SS locking Southco latch is standard in 06 Door vented at the top and the bottom.	1
60-08-0800	S OPT S	B1, Thermostat, Digital, Pro Air, With Manual Control LOCATION: On 1st action area wall. Standard in 2006	1
60-11-0200	S	B1/2, Cab/Body Pass-Through LOCATION: Pass-thru between cab and module. INSTRUCTION: There shall be a pass-through access window approx. 16"H x 17.5"W with a sliding plexiglass window, in formica covered wood frame.	1
60-12-0600	S	B1/2, Heat/Cool Unit, Patient Compt, Pro-Air #935 INSTRUCTION: Mounted over walkthru. Double Vents on the underside of the HVAC Cabinet Controls to be located in the rear switch panel.	1
63-36-0600	S OPT S	B2, OPTION 2 - ALS Cabinet ,27.5" W, 3-Section INSTRUCTION: Top: 30"H Aluminum Slat Door, roll behind false wall. Dealer has been advised that the 12V & 115V will be boxed out into the ALS with the roll behind wall door. NON Locking Bar Latch [2] adjustable shelves Lower Center (2) Drawers: 6.00" H x 25.5"W Top drawer Should be installed 32" from the top of compartment in cabinet and the 2nd drawer directly under it. Brushed aluminum face on drawer Locking round SS SouthCo latch. Install gas charged hold-open on the bottom of the drawer.) Gas strut to hold open and closed. 7-10-06 per Dan and Andrew, these drawers are NOT adjustable Bottom: 25"H Aluminum slat roll-up door, roll behind wall Non-locking Bar Latch handle. [1] adjustable Make this lower cabinet as tall as possible to close off the void between the bottom of the 2nd drawer and the top of this cabinet. Rubbermat on the bottom of each cabinet section, drawer, and shelf.	1
	S		
*** PATIENT COMPARTMENT SEATING ***			
64-01-1200		Vacuumed Formed Upholstery (AD166 AD170 AD180 PD156 PD168) INSTRUCTION: EVS Vacuum formed seats & backrests only. Armrests and all trim panels to be machine stitched using EVS Companion II material.	1 1
64-04-0600	OPT	Sect 1, Att. Seat, EVS Child Seat, On Swivel Base (VF) INSTRUCTION:	1

PART NO	S	DESCRIPTION	QTY
		EVS seat with built-in child safety seat. EVS 185S swivel type seat base. NO ARMREST.	
64-06-1800	S	Sect 2, CPR Seat, 43" Wide With Fold Down Backrest	1
64-07-0200		Sect 2, Storage Under CPR Seat - Hinged on aisle INSTRUCTION: Seat cushion hinged on aisle side, by the cot.	1
64-10-2000	S	Sect 2/3, Squad Bench, 21"Dx102"Wx16"H	1
	S	INSTRUCTION: (2) lids with storage under forward section, Gas strut hold opens and [1] paddle latch.	
64-14-0200		Sect 2/3, Back Rests, (2) Above Squad Bench	1
	S	Bottom one cut back for the armrest	
64-16-0200	OPT	Sect 2, No Posts and Cups Required At This Time	1
64-18-0800	OPT	Sect 2, Armrest, MVP Style, Fold Down, Squad Bench INSTRUCTION: MVP fold down style armrest -- top and side padded.	1
64-22-0400	OPT	Sect 2, Sharps/Waste, Top of Squad Bench, Flip-Up Cushion	1
	S	INSTRUCTION: -- Sharps & Waste @ head of squad bench. -- Hinge left side of forward seat cushion for access. -- Vinyl pull tab on rearward edge of cushion.(Only on machine stitched upholstery, can not have pull tab for vacuum formed upholstery.) -- Drop-in storage (no box) under flip cushion with stainless steel covering inside of cushion. -- Install spacer so containers can be stored with lids on.	
		*** CURBSIDE CABINETS - PATIENT COMPARTMENT ***	
68-10-2600		Sect 2/3, Squad Bench Cabinet, Two-Section	1
	S	INSTRUCTION: Cabinet to be divided into (2) sections by a center fixed divider.	
68-12-0800	OPT	Sect 2/3, Restocking Plexiglas Doors, Sliding Flip Up	1
	S	LOCATION: On Squad Overhead Cabinet	
68-14-1400		Sect 2/3, Handles, Full Length Aluminum LOCATION: On the squad overhead cabinet doors.	1
		*** PATIENT COMPARTMENT EQUIPMENT/COMPONENTS ***	
70-02-0800	S OPT	IV Holders, (2) Cast Products #2008-1, Ceiling - T4-T5	1
	S	LOCATION: (1) over cot (1) over squad bench [2] have been deleted	
70-10-1500	OPT	Cot Mount, Stryker #6370 Single Position, Floor Mount	1
	S	INSTRUCTION: For Cot Model: MX Pro (for positioning of cot mounts only)	
70-14-0400	OPT	Cot Mount Location, Center Mount	1
70-17-0200		No Cot Stop Required at This Time	1
72-02-1200		Assist Rails, (1) 90" x 1.5", (1) 60" x 1.5", Brey Krause INSTRUCTION: (1) 90"x 1.5" - over cot.	1

PART NO	S	DESCRIPTION	QTY
		(1) 60" x 1.5 " - over squad bench.	
72-10-0200		Signs, "No Smoking Oxygen Equipped" & "Fasten Seatbelts" LOCATION: (1) on 1st action area wall.	1
		* * * MEDICAL OXYGEN & ENVIRONMENTAL SYSTEMS * * *	
74-02-0200		Oxygen, 3000 Liters Minimum	1
74-02-0600	OPT	Oxygen, (2) Outlets - 1st Action Area & Squad	1
	S	INSTRUCTION: (1) on the 1st action area wall (move this over as far as possible toward the digital thermostat (1) over squad bench, head end of overhead cabinet SEE PRINTS	
74-04-0400	S OPT	Oxygen Outlet, (1) Additional, Specify Location	1
	S	INSTRUCTION: (1) additional outlet in the ceiling. SEE PRINT	
74-04-1200	S OPT	Oxygen Outlets to be Cemtron/NCG Brand	1
	S		
74-06-0600		Flowmeter, (1) Oxygen, Gravity Type LOCATION: SHIPPED LOOSE	1
74-10-0600		Regulator, Oxygen LOCATION: On O/2 hose in D-1 compartment.	1
74-18-0400	OPT	Oxygen Shut-Off, Electric Solenoid With Manual Bypass	1
	S	INSTRUCTION: Manual by-pass valve on 1st action area wall. (1) switch in the rear switch panel. move this over as far as possible toward the digital thermostat	
74-20-0800	S	Suction & Aspiration Systems, SSCOR/Thomas, D2 INSTRUCTION: [1] SSCOR 20001/02 disposable canister, stainless bracket and outlet in a cabinet below the 1st AA. The Wall-mount vacuum gauge is on the 1st AA wall. move this over as far as possible toward the digital thermostat Install the Thomas brand vacuum pump in the upper left corner of the D-4 compartment in a metal cage. Keep the cage to this compressor as small as possible and as rearward as possible in the compartment<< 7-20-06 per email from Andrew, compressor is to be located as this verbage states and not what is on the prints. Upper Left hand corner. Brad was advised by phone and fax.	1
	S	See Print	
74-22-0200		Sharps & Bio-Hazard Containers, Racksack With Bags LOCATION: SHIPPED LOOSE	1
		* * * COMMUNICATION & LOOSE EQUIPMENT * * *	
76-02-0400		Patient Code Signal System, With (3) Switches & Buzzer LOCATION: Cab console and rear switch panel.	1
76-06-0200		Radio Antenna Pre-Wire, (2) Base, Power, Ground & Coax INSTRUCTION: Antennae/Radio (2) bases and coax. Power and ground wires. Run from: (1) Center front of module roof. (1) Center center of module roof. Run to: Both to behind passenger seat in cab.	1

PART NO	S	DESCRIPTION	QTY
76-08-0400	OPT S	Cell Phone/Radio Equip, (1) Each Pwr & Grnd, Coax Cable INSTRUCTIONS: (1) Antennae base - Run from: Center rear of module roof. Run to:1st action area with grommetted SS Plate	1
78-02-0600		(2) Fire Extinguishers, ABC 5 lb With Mounting Brackets LOCATION: SHIPPED LOOSE	1
80-04-0200		*** PAINTING, LETTERING & STRIPING *** Body Surface Preparation with Corrosion Inhibitor	1
80-04-0400		Paint Preparation & Processes	1
80-04-1000	OPT S	Body Paint Color, Sikkens, Single Color	1
	S	INSTRUCTION; Color Pierce Red #268 #FLNA 3225 on Cross Ref sheet for pierce 268 red	
80-05-10A	U OPT S	Ford Chassis Repaint Color Pierce Red #268 Sikkens #FLNA 3225 on Cross Ref sheet for pierce 268 red	1
80-08-0400	OPT S	Paint Sample Color Pierce Red #268 Sikkens #FLNA 3225 Sample sent to Andrew for approval 5-10-06 DB Sample approval by dealer required >>PRIOR<< to painting the unit. 5-24-06 sample has been approved for painting per andrew on 5-19	1
84-06-5000	OPT S	Main Scotchlite Stripe, 1-Color, "Z" Type LOCATION: Chassis And Body Sides, Rear Body. Start 2" below the cab window with the "Z" stripe going through the conversion and wrap around the rear of conversion. >>NO<< photos have been provided	1
	S	INSTRUCTION: COLOR: White Reflective as there is no silver reflective WIDTH: 8"	
84-07-0000		Non Metallic or Pearl Paint Color	1
84-10-0200		No 1/4" Pinstriping Required At This Time	1
84-22-0000	S	Pinstripe, 3/4" W -"C" Style Rubrail, Reflective,Specify Col SPECIFY COLOR: Install 3/4" wide WHITE reflective stripe through the center of the "C" style rubrail.	1
88-04-0400	OPT	Decals, "Ambulance" & "Star of Life" Pkgs, SHIPPED LOOSE	1
88-04-0600	S	Decals, (1) 32" "Star of Life" Installed on Roof Color: >>INSTALL<<Roof SOL	1

PART NO	S	DESCRIPTION	QTY
	S	Standard Intense Blue Vinyl #220/225-47	
		>>>>NO LETTERING BY MEDTEC<<<<	
		* * * MISCELLANEOUS * * *	
90-02-0100		Vehicle Operator's Manual, Hard Cover Binder - Ford	1
90-06-0600		Operating Instructions, Video Tape	1
90-06-0800		Electrical Schematics CD	1
90-07-0400		Fuel Fill	1
96-00-0300	OPT	Change Order Approval CHANGE ORDER APPROVAL	1
<p>Please review attached Production Change Order. If correct, sign and return. If incorrect, make changes and return (a corrected copy will be returned to you).</p> <p>Please note any applicable Time Fence charges will be enforced.</p> <p>SIGNING THIS PRODUCTION CHANGE ORDER WILL VERIFY THAT DEALER AND/OR CUSTOMER APPROVE OF CHANGES TO THE ORIGINAL APPROVED PRODUCTION ORDER AND DRAWINGS.</p> <p>DEALER APPROVAL:</p> <p>_____</p> <p>DATE:</p> <p>_____</p> <p>CUSTOMER APPROVAL:</p> <p>_____</p> <p>DATE:</p> <p>_____</p>			
		DEALER ===== DEALER ===== DEALER	1